



RV WI-FI

Quick start User Guide


1

Setting up the SIM card

a Activate and add data to your SIM card as per instructions on the sim card packet.



b Break your SIM card down to the Nano size.



c Remove the middle adapter from the adapter pack and place the activated Nano Sim in the recess of the adapter.



d Place the sim/adapter into the sim card slot, making sure the sim stays in the recess of the adapter.



2

Setting up the Antenna's

Stick Antenna's

or

3 in 1 Antenna

Attach all four antenna's to the antenna ports.

Install the 3 in 1 antenna on the roof.

a 2.4 stick antenna's to top and bottom left hand side.

a 2.4 stick antenna to top left antenna port.

b 4.0/LTE stick antenna's to top and bottom right hand side.

b From 3 in1 antenna, WIFI to bottom left port, 3G to Bottom right port, 4G to top right port.



3

Setting up the Power Cord

Plug the 12volt power socket into a single power socket.



X

4

Connecting to the WIFI

- Power on the router and wait 5 minutes.
- On your device (phone/laptop etc.), go to : SETTINGS.
- Go to: WIFI.
- Wait for RV WIFI to come up as a WIFI option.
- Click on: RV WIFI
- You will be asked for a WIFI Password or Security Key. Type in: `rvwifi1234` (all lower case and no spaces).
- Click on: connect.
- Wait for confirmation of connection.
- Scan the QR code on the front of the router for full instructions and to change your WIFI password.